



Information: W: PurrProp.Com

E: [purrprop.com@gmail.com](mailto:purrprop.com@gmail.com)

A: PO Box 5404 Manly. Q4179. Australia

TIP: Prior to starting: A good idea is to place the can of PurrProp Etch Primer in the sun to warm (as well as the activator) so as to aid in speeding up the curing process.

## PREPARATION:

- Shaft, prop, rudder etc, all need to be sanded close to 80 grit, removing any traces of old Anti Foul from the surface. Once completed, dust down the surface and remove all debris.
- Now is a great time to mix the PurrProp Etch Primer Base together with the Activator.
- Mix the contents of the PurrProp Etch Primer Base thoroughly before adding the Activator
- The PurrProp Activator is then added to the PurrProp Etch Primer Base and stirred well.
- Allow to stand for 5 minutes while the chemical reacts.
- While the chemicals are reacting, use one of the PurrProp Cleaning Sachets to wipe down the entire surface to be coated. Then, discard the first Sachet and wipe the surface down again by using a second clean PurrProp Cleaning Sachet.
- Once cleaned, the surfaces can now be acid treated by liberally saturating all surfaces using the cloth contained within the PurrProping Metal Conditioning Sachet. (Please note to always wear eye and hand protection as this product contains an acid solution). Once the surface is saturated, now wipe the surface dry using the microfibre cloth included in your PurrProp kit.
- Make sure that the surface is dry wiped before immediately applying the PurrProp Etch Primer.

## APPLICATION:

- Apply the mixed PurrProp Etch Primer, painting all the surface by using the disposable brush and making sure that there are no missed areas, drips or runs in the coating.
- IMPORTANT and CRITICAL!! Do not let the PurrProp Etch Primer cure, as it must be tacky or sticky to the touch for the PurrProp Clear Coating to adhere to it. It may take between 15 mins in summer to 1 hour in winter for this tacky surface to appear and be ready for the final and main coating using PurrProp Clear Coat.
- When the tacky surface is achieved, Immediately apply PurrProp.com ClearCoat (brush type) using the foam brush contained in the kit. Make sure that there are no missed areas, runs or drips in the coating.
- Leave the PurrProp System time to cure the silicone ClearCoat (allow 8 hours) before launching.

